

FUEL FILTER




Replacement guideline

Interval

105,000 km

Purpose and Function

The fuel filter filters out any impurities in the fuel from the fuel tank to the engine.



If overused without replacement ...

- As fuel filter degrades, clogs may reduce engine power.